


## PARTS LIST:

**ASSEMBLY INSTRUCTIONS FOR FUN4723 DOUBLE TROUBLE DEMON CLOWN  
THIS IS NOT A TOY. 14+ AGE. PLEASE FOLLOW DIRECTIONS FOR EASY SET-UP.**

Product number: FUN4723

Company name: FUN.com

Company website: www.fun.com



**ONCE ASSEMBLED AND PLUGGED-IN, DOUBLE TROUBLE WILL HAVE AUDIO, LIGHT-UP EYES, MOVING MOUTHS AND SIDE TO SIDE MOVEMENT. ITEM WORKS WITH OR WITHOUT STEP PAD. WHEN POWER SWITCH IS SET TO ON, DOUBLE TROUBLE IS ACTIVATED BY SOUND SENSOR. TO ACTIVATE BY STEP PAD, SET POWER SWITCH TO OFF. KNOB ON CHEST/MODULE SPEAKER BOX ADJUSTS VOLUME.**

## **DOUBLE TROUBLE DEMON CLOWN WILL BE BUILT FROM THE FLOOR UP.**


### **STEP 1**

**Lay base on floor, pegs up and large section forward.**

**Attach Leg Poles – 2 on each side**

**Slide Shoes over top of poles**

**Slide Pants over top of poles**




### **STEP 2**

**Attach Chest/Module to top of Leg Poles, speaker facing back**

**Attach Waist Ring to base of Chest/Module**

**Lift Pants over Waist Ring**

**Add Shoulder Frame to top of Chest/Module**



### **STEP 3**

**Drape Shirt over upper body, opening facing back**

**Attach Heads to top of Chest/Module through Shoulder Frame**

**Connect wires from Chest/Module to each head**



### **STEP 4**

**Inset Arms through sleeves to attach at shoulder of Chest/Module**

**Attach Hands to bottom of Arms, connect velcro at base of sleeve to wrist**



### **STEP 5**

**Add Neck Sash around Heads**

**Connect Plug to speaker box (right jack)**

**Connect Step Pad to speaker box (left jack)**



**FCC:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver.
- Consult the dealer or an experienced radio TV technician for help.